FACTORY SEAM

② INSTALL POLYGUARD CR PIT TOP CORNER BOOT INTERFACING WITH THE ADHESIVE OF THE POLYGUARD CR SEAM TAPE

① POLYGUARD UNDERSEAL CR SEAM TAPE

PIT WALL SUBSTRATE (POLYGUARD POLYFLOW 15 , SLURRY WALL, ETC.)

5"

5"

6"

IMAGE 1

③ ROUGH-FIT THE FIELD SHEET OF THE POLYGUARD CRM MEMBRANE AROUND THE TOP OF THE PIT WALLS

IMAGE 2

④ PREPARE THE POLYGUARD CRM MEMBRANE FIELD SHEET WITH POLYGUARD CR SEALANT AND THEN POLYGUARD CR LIQUID MEMBRANE TO WET SET THE POLYGUARD CRM MEMBRANE OVERLAP

⑤ INSTALL POLYGUARD UNDERSEAL CRM ONTO THE PIT SIDEWALL AND A MINIMUM 6" ONTO THE UNDERSEAL CRM FIELD SHEET AROUND THE TOP OF THE PIT

6"

IMAGE 3

POLYGUARD FABRIC TAPE, EXTEND 6" TO EACH SIDE OF THE POLYGUARD CRM MEMBRANE END LAP

⑥ PREPARE & CLEAN THE POLYGUARD CRM MEMBRANE FABRIC 6" TO EACH SIDE OF THE END LAP

⑦ APPLY POLYGUARD CR SEALANT TO THE CLEANED AREA AT THE RATE OF 50-75 SF / GAL

⑧ COVER THE POLYGUARD CR SEALANT WITH POLYGUARD FABRIC TAPE

⑨ ROLL THE POLYGUARD FABRIC TAPE WITH A 75-LB HARD SURFACE ROLLER

6"
6"

IMAGE 4

CRH20 SECTION @ CRM MEMBRANE PIT SIDEWALL TRANSITION AT TOP OF WALL

Polyguard Products, Inc.
P.O. Box 755 - Ennis, TX 75120
Phone: 214-515-5000
Web Site - www.polyguard.com

The information provided is based on data and knowledge considered to be true and accurate and is offered for the users' consideration, investigation and verification, but we do not warrant the results to be obtained. Please read all data sheets, statements, recommendations or suggestions in con-junction with our conditions of sale, which apply to all goods supplied by us.

NOT TO SCALE

EFFECTIVE DATE:
10/01/2022

SUPERCEDES:
02/04/2022