



1. Cut 2 - 18" x 18" pieces of Polyguard CR Seam Tape -
A. (A) & (B) piece cut to dimensions above and mirror image
2. Carefully score 3/4" release film at angled edge ensuring not to cut through the tape - remove the film
3. Adhere piece (A) and (B) at exposed 3/4" compound - roll tight

CRH21 SECTION @ FIELD MADE OUTSIDE CORNER BOOT DETAIL

<small>The information provided is based on data and knowledge considered to be true and accurate and is offered for the users' consideration, investigation and verification, but we do not warrant the results to be obtained. Please read all data sheets, statements, recommendations or suggestions in conjunction with our conditions of sale, which apply to all goods supplied by us.</small>	NOT TO SCALE
	EFFECTIVE DATE: 07/15/2024
	SUPERCEDES: 10/01/2022