



**FT7a** SECTION @ TRM SILL - STEM WALL TRANSITION TO ICF BLOCK (OPTION #1)

MATERIAL SEPARATED FOR CLARITY  
© POLYGUARD PRODUCTS, INC.

**GENERAL NOTE: IF ADHESIVE IS REQUIRED FOR SEAMS OR END LAPS, DO NOT USE POLYGUARD 650 WB LIQUID ADHESIVE.**

<small>The information provided is based on data and knowledge considered to be true and accurate and is offered for the users' consideration, investigation and verification, but we do not warrant the results to be obtained. Please read all data sheets, statements, recommendations or suggestions in conjunction with our conditions of sale, which apply to all goods supplied by us.</small>	NOT TO SCALE
	EFFECTIVE DATE: 01/06/2025
	SUPERCEDES: 10/25/2024