



1. Cut 2 - 12" x 18" pieces of Polyguard 650 or Polyguard Balconyguard Membrane -
 - A. (A) & (B) piece cut to dimensions above and mirror image
2. Score 3/4" - 1" release film at angled edge - remove the film
3. Adhere piece (A) and (B) at exposed 3/4" - 1" compound - roll tight

US24

SECTION @ FIELD MADE OUTSIDE CORNER BOOT

<small>The information provided is based on data and knowledge considered to be true and accurate and is offered for the users' consideration, investigation and verification, but we do not warrant the results to be obtained. Please read all data sheets, statements, recommendations or suggestions in conjunction with our conditions of sale, which apply to all goods supplied by us.</small>	NOT TO SCALE
	EFFECTIVE DATE: 10/01/2022
	SUPERCEDES: 02/01/2022