



POLYGUARD UNDERSLAB TRM REPAIR AREA

STEP #1: POLYGUARD LM-95 OR TRM SEALANT APPLIED AND TOOLED TO MINIMUM 60 MILS OVER CLEAN AND DRY POLYGUARD UNDERSLAB TRM HDPE FILM REPAIR AREA, EXTEND MINIMUM 1" BEYOND REPAIR AREA IN ALL DIRECTIONS

STEP #2: POLYGUARD FABRIC TAPE OVER CLEAN AND DRY UNDERSLAB TRM AND REPAIR SEALANT PREPARED WITH POLYGUARD 650 LT LIQUID ADHESIVE OR CALIFORNIA SEALANT APPLIED AT A RATE OF 50 - 75 SF / GAL, EXTEND FABRIC TAPE MINIMUM 6" BEYOND DAMAGE IN ALL DIRECTIONS

EXISTING POLYGUARD UNDERSLAB TRM TO REMAIN, CLEAN AND DRY IN PREPARATION FOR POLYGUARD OVERLAY MATERIALS

UST19 ELEVATION @ UNDERSLAB TRM - REPAIR PATCH LESS THAN 2"

The information provided is based on data and knowledge considered to be true and accurate and is offered for the users' consideration, investigation and verification, but we do not warrant the results to be obtained. Please read all data sheets, statements, recommendations or suggestions in conjunction with our conditions of sale, which apply to all goods supplied by us.	NOT TO SCALE
	EFFECTIVE DATE: 12/17/2024
	SUPERCEDES: 12/05/2024