



1. CUT 2 - 1'-0" X 1'-0" PIECES OF POLYGUARD 650 TRM
2. PIECES (A) & (B) CUT TO DIMENSIONS ABOVE AND MIRROR IMAGE
3. SCORE 3/4" - 1" RELEASE FILM AT ANGLED EDGE - REMOVE FILM
4. ADHERE PIECE (A) AND (B) AT EXPOSED 3/4" COMPOUND - ROLL TIGHT

UST24 ELEVATION @ UNDERSLAB TRM - FIELD-MADE OUTSIDE CORNER BOOT