



POLYGUARD 650 TRM EXISTING FIELD SHEET TO REMAIN

STEP #1: REPAIR DAMAGED AREAS, FISHMOUTHS, AND / OR BUBBLES LARGER THAN 4" IN DIAMETER; REMOVE ANY MATERIAL THAT DOES NOT ALLOW POLYGUARD 650 TRM PATCH TO BE FULLY ADHERED OR LAY FLAT

STEP #2: APPLY POLYGUARD 650 TRM 6" LARGER THAN DAMAGE IN ALL DIRECTIONS IN EXISTING MEMBRANE PREPARED WITH POLYGUARD 650 LT LIQUID ADHESIVE OR POLYGUARD CALIFORNIA SEALANT APPLIED AT A RATE OF 250 - 300 SF / GAL OR POLYGUARD 650 WB LIQUID ADHESIVE AT A RATE OF 350 - 400 SF / GAL

STEP #3: POLYGUARD LM-95, DETAIL SEALANT PW, OR TRM SEALANT APPLIED TO PATCH PERIMETER EDGES TO MINIMUM 30-MIL THICKNESS; EXTEND MINIMUM 1" TO EACH SIDE OF EDGE AS EDGE SEAL

WPT1 ELEVATION @ 650 TRM - SELF-ADHERED MEMBRANE REPAIR PATCH

GENERAL NOTE: IF ADHESIVE IS REQUIRED FOR SEAMS OR END LAPS, DO NOT USE POLYGUARD 650 WB LIQUID ADHESIVE.

<small>The information provided is based on data and knowledge considered to be true and accurate and is offered for the users' consideration, investigation and verification, but we do not warrant the results to be obtained. Please read all data sheets, statements, recommendations or suggestions in conjunction with our conditions of sale, which apply to all goods supplied by us.</small>	NOT TO SCALE
	EFFECTIVE DATE: 12/17/2024
	SUPERCEDES: 12/10/2024