

IMAGE 1

CORNERS CAN BE MADE IN FIELD OR PURCHASED PREFORMED BY POLYGUARD. TO MAKE A 12" X 12" BOOT USE A 24" X 24" PIECE OF POLYGUARD 650 MEMBRANE. FOR ADDITIONAL HEIGHT REQUIREMENT ADD POLYGUARD 650 MEMBRANE TO THE VERTICAL LEGS. (REFERENCE POLYGUARD US INSIDE CORNER DETAIL FOR COMPLETE INSTALLATION INSTRUCTION)




IMAGE 2

CUT AND REMOVE A SQUARE PIECE OF POLYGUARD 650 MEMBRANE FROM THE END CORNER. DIMENSION THE STARTING POINT OF EACH CUT FROM THE CORNER, AND ALONG AN EDGE, A DISTANCE EQUAL TO THE HEIGHT OF THE VERTICAL LEG OF THE BOOT. CUT INWARD FROM THE EDGE TO THIS DISTANCE AND DISCARD THE OFF FALL




IMAGE 3

REMOVE 1 INCH OF THE FILM SO THE (A) AND (B) EDGES MEET IN THE VERTICAL LEG OF THE BOOT. ROLL SEAM WITH A ROLLER AND UNFOLD TO CREATE THE INSIDE CORNER BOOT

**US22**

**SECTION @ 650 MEMBRANE BOOT FOR US INSIDE CORNER**

<small>The information provided is based on data and knowledge considered to be true and accurate and is offered for the users' consideration, investigation and verification, but we do not warrant the results to be obtained. Please read all data sheets, statements, recommendations or suggestions in conjunction with our conditions of sale, which apply to all goods supplied by us.</small>	NOT TO SCALE
	EFFECTIVE DATE: 07/15/2024
	SUPERCEDES: 10/01/2022